
LAB 6: Lucas Kanade

Assignment 1: Object Tracking

Source code:

```
import numpy as np
   lk params = dict(winSize=(15, 15), maxLevel=2,
   grayI1 = cv2.cvtColor(I1, cv2.COLOR BGR2GRAY)
    grayI2 = cv2.cvtColor(I2, cv2.COLOR BGR2GRAY)
   optical flow, status, err = cv2.calcOpticalFlowPyrLK(grayI1, grayI2, roi,
None, **lk params)
   good points = optical flow[status == 1]
   roi = good points.reshape(-1, 1, 2)
cap = cv2.VideoCapture('Datasets/video.mp4')
ret, prev = cap.read()
x, y, w, h = cv2.selectROI('Select ROI', prev, False)
roi = np.array([[[x + w / 2, y + h / 2]]], dtype=np.float32)
cv2.destroyWindow('Select ROI')
while cap.isOpened():
    ret, frame = cap.read()
   roi = trackObject(prev, frame, roi)
   prev = frame.copy()
    if cv2.waitKey(30) & 0xFF == 27:
cap.release()
cv2.destroyAllWindows()
```

Result:



Assignment 2: Object Speed Estimation Source code:

```
import numpy as np
   lk params = dict(winSize=(15, 15), maxLevel=2,
    optical flow, status, err = cv2.calcOpticalFlowPyrLK(grayI1, grayI2, roi,
None, **lk_params)
    speedMagnitude = np.sqrt(optical flow[0][0][0] ** 2 +
optical flow[0][0][1] ** 2)
    good points = optical flow[status == 1]
    roi = good points.reshape(-1, 1, 2)
    return roi, speedMagnitude
cap = cv2.VideoCapture('Datasets/video1.mp4')
ret, prev = cap.read()
if not ret:
   cap.release()
x, y, w, h = cv2.selectROI('Select ROI', prev, False)
while cap.isOpened():
    ret, frame = cap.read()
    roi, speedMagnitude = trackObject(prev, frame, roi)
    cv2.rectangle(frame, (int(x - w / 2), int(y - h / 2)), (int(x + w / 2),
    cv2.putText(frame, f'Speed: {speedMagnitude:.2f}', (10, 30),
   cv2.imshow('Object Tracking', frame)
   prev = frame.copy()
    if cv2.waitKey(30) & 0xFF == 27:
cap.release()
cv2.destroyAllWindows()
```

Result:

